

Remove clips in the rear cover using a plastic pry bar.



Install brackets (57110-03) in the same position using the original clips.



Remove the 4 screws in the top of the bulkhead.



Install brackets (57110-03) in the same positions angled downwards using the original bulkhead screws. Ensure the screw is seated properly in the hole.



10Nm



Bend the bulkhead brackets so that they become horizontal.



Fasten the roof lining board with lining screws as shown below.



36675-03 / 36677-03

