


### **ASSEMBLY INSTRUCTION**

**Maxus ED-3 Floor mount** 






- First remove the rubber mat from the floor in the cargo area.
- The white original floor must not be removed. The Modul-Floor will be placed on top of the white floor.




• When rubber mat is removed, reattach the black plastic entry lists.






- Place the Modul-Floor and precheck the fitting.
- Make sure that the central Modul-Floor parts are placed in a centred position in the vehicle and mark the correct place.



- Clean, prime and glue the fastening plates on the central Modul-Floor parts. The plates should be parallel with the inside rail edge.
- See slide 5 (L1-vehicle) and slide 6 (L2-vehicle) for measurements and placement.
- First use Sika Cleaner P on the plate and the underside of the floor part where the plate will be positioned.
- Use Primer to both the plate and the Floor on the given positions and then put the glue.
- The plates must be glued with the countersunk holes facing up.






#### Glue instructions


- 1. Clean the surfaces
- 2. Apply primer on all parts
- 3. Let primer rest for 10 min and then apply glue.
- 4. Place parts and let the glue cure for 2 hours















- When the glue has hardened, place the floor sections in the middle of the vehicle and align them to the center.
- Put some glue under the centred Modul-Floor parts to keep it in place.
- Fasten the floor sections using the self threading screws. (Wingdril 6,3x45)




- All screws are drilled and fastened to the vehicle beams. Use two screw per plate.
- Use the outer holes of each fastening plate. If the screw collide with existing screws (connected to the white original floor), use another hole in the plate.
- Tighten the screw head and make it as flat as possible to the plate surface. Make sure that the screw does not make the hole in the plate too large.





• Glue and install all floor side-parts in the vehicle. (Same glue procedure as before)



• Fix the edging strips (see red lines in picture) with glue, screws or rivets.

